

## New information on Installation:

### Notes for installing:

When using wire ties, tighten firmly but don't over tighten they will cut into Padding.

If your padding came without sticky tape and you want to put it on yourself go to your local hardware store and buy some 1" wide 2 sided PSA tape acrylic backed.  
Clean area on the padding with rubbing alcohol and apply tape.

If you prefer to use contact spray cement use 3M 77 again clean area with rubbing alcohol before applying

To form or shape to Roll Bar Tubing: warm padding with a heat gun prior to and during bending.

US2000 US1750 US1500 US1000 Padding



**2" 1 3/4" 1 1/2" 1" Roll Bar Padding**